



SOFT-WALL & MACHINE PROTECTION SOLUTIONS

UHTS

INCLUDES:

- 1 EA - UHTS CURTAIN
- 1 EA - STORAGE BRACKET
- 1 EA - SUPPORT BRACKET

REQUIRED TOOLS:

- MEASURING TAPE
- 10 EA - SELF-DRILLING SCREWS 1/4" W/ FLAT/SPRING WASHERS
- POWER DRILL W/ TOOL FOR SCREWS

INSTALLATION INSTRUCTIONS:

ALL BRACKETS MUST INSTALL TO SOME KIND OF REINFORCEMENT IN THE SIDEWALLS. CURTAIN CAN BE MOUNTED W/ HINGE ON ROADSIDE OR CURBSIDE. ROADSIDE INSTALLATION SHOWN.

1. INSTALL THE HINGE BRACKET 2" FROM CEILING USING 4 SELF DRILLING SCREWS.
2. INSTALL THE SUPPORT BRACKET ON THE OPOSITE SIDEWALL 4" FROM CEILING USING 4 SELF DRILLING SCREWS.
3. OPEN THE CURTAIN AGAINST SIDEWALL AND MARK THE LOCATION FOR THE STORAGE BRACKET. INSTALL USING 2 SELF DRILLING SCREWS 4" FROM CEILING.

